



## D-WELL Universal Super Roof Rack

The assembly manual of adjustable mechanism and dual-purpose roof rack

If R size of the cargo rails is bigger in Japan or other car type, please refer the below steps to change new patch steel.



After change new patch steel, please paste sponge rubber to protect the surface of cargo rails.

1. After loosening the screw of back knob, adjust the two jigs to fit the width of roof cargo rails.
2. Put on the two side of roof cargo rails, then adjust the front lock to rails.
3. When the rails is tighten, fix the front screw to tight.
4. Tighten the back knob and lock the front cover.
5. It would complete installation.

### Roof rails with a gap between rails and roof:



### Solid roof rail(with no gaps):

